

French Toast

Ingredients

1 teaspoon Loprofin Egg Replacer

3 teaspoons Loprofin PKU Milk

Small knob of margarine or butter

1 slice Loprofin Sliced Loaf

Sugar and cinnamon to serve



Method

1. Blend together the egg replacer and liquid until smooth.
2. Heat the fat in a frying pan. Dip the bread in the 'egg' mixture making sure that both sides are covered. Fry on both sides until golden brown. Serve hot sprinkled with sugar and cinnamon.